


USB422 USB to RS422/485 CONVERTER



S5 - MODE

- 1 RS422
- 2 RS485
- 3 S1 CLOSED – PULLUP TO A
- 4 S2 CLOSED – PULLDOWN TO B

S3 - B & Z CIRCUIT


- 5 - B & Z DISCONNECTED, NO RX TERMINATOR
- 6 - B & Z DISCONNECTED, RX TERMINATOR
- 7 - B & Z CONNECTED

S4 - A & Y CIRCUIT

- 8 - A & Y DISCONNECTED, NO TX TERMINATOR
- 9 - A & Y DISCONNECTED, TX TERMINATOR
- 10 - A & Y CONNECTED, NO TX TERMINATOR
- 11 - A & Y CONNECTED, TX TERMINATOR

EXAMPLES: 1,6,9 – RS422, TERMINATORS ON BOTH SIDES
 2,7,11 - RS485 WITH TERMINATOR

RS485



RS422

